

Air Conditioning Spring Checklist

| Remove the Cover |
|---|
| Inspect Unit Panels |
| Check and Replace Pipe Insulation |
| Remove Brush and Trash from around the Unit |
| Change the Air Filters |
| Clean the Grills |